


SPI communication between a Nucleo-STM32L476 board and a BME280 sensor

Jean-Christophe Toussaint
Grenoble INP - Phelma

The Serial Peripheral Interface (SPI) is a specification of serial, synchronous and full duplex communication between a master (or multiple masters) and a single or multiple slave devices.

This presentation is aimed at helping users to realize such a communication between a Nucleo board STM32L476RG and an SPI pressure-temperature-humidity Sensor BME280.

This example was developed using the Keil programming environment.




Nucleo64-STM32L476RG : CubeMx configurator

Run CubeMX

New Project

Load Project

Help



Project Settings

Project Name
nucleoL4_BME280

Project Location
C:\Users\JC\Documents\STM32


Toolchain Folder Location
C:\Users\JC\Documents\STM32\nucleoL4_BME280_SPI

Toolchain (IDE)
MDK-ARM V5 = KEIL ☐ Generate Under Root


Linker Settings
Minimum Heap Size 0x200
Minimum Stack Size 0x400

Mcu and Firmware Package
Mcu Reference
STM32L476RGTx
Firmware Package Name and Version
STM32Cube_FW_L4_V1.6.0
☒ Use Default Firmware Location
C:\Users\JC\STM32Cube\Repository\STM32Cube_FW_L4_V1.6.0


Nucleo64-STM32L476RG : SPI and USART




Choose SPI2 as the SPI bus.
PB10 and (PC2, PC3) are then automatically selected as circled beside.
PB15 is used as a software Chip Select pin. Change its name to SPI2_CS1.



Choose USART2 as the serial bus
PA2 and PA3 are then automatically selected as circled beside



Nucleo-L476RG and BME280 Wiring




/** SPI2 GPIO Configuration

PC2 -----> SPI2_MISO

PC3 -----> SPI2_MOSI

PB10 -----> SPI2_SCK


DO NOT PLUG THE NUCLEO TO USB PORT
Before Double-Checking your wiring



Now look at the Nucleo [schematics](#). As we can see in the picture above, the USART_TX and USART_RX ports are connected to PA2 and PA3 pins. This means that the Nucleo board is configured to use the USART2 peripheral of target MCU.

Nucleo64-STM32L476RG : clock configuration

The clocks configuration used for this project are :



Nucleo64-STM32L476RG : SPI2 and USART2 configuration

Mid

Connectivity

SPI2

USART2

SPI2 Configuration

Parameter Settings User Constants NVIC Settings DMA Settings GPIO Settings

Configure the below parameters :

Search : Search (Ctrl+F)

Basic Parameters

Frame Format Motorola

Data Size 8 Bits

First Bit MSB First

Clock Parameters

Prescaler (for Baud Rate) 2

Baud Rate 4.0 MBits/s

Clock Polarity (CPOL) High

Clock Phase (CPHA) 2 Edge


Advanced Parameters

CRC Calculation Disabled

NSS Signal Type Software

Baud Rate should be less 10 MBits/s for BME280 sensor

Nucleo64-STM32L476RG : USART2 configuration



The image shows the STM32CubeMX software interface. On the left, the 'Connectivity' tab is selected, and a red arrow points to the 'USART2' icon. The main window displays the 'USART2 Configuration' dialog box. The 'Parameter Settings' tab is active, showing a table of configuration parameters. A red box highlights the 'Basic Parameters' section of the table.


USART2 Configuration	
<input checked="" type="checkbox"/> Parameter Settings <input checked="" type="checkbox"/> User Constants <input checked="" type="checkbox"/> NVIC Settings <input checked="" type="checkbox"/> DMA Settings <input checked="" type="checkbox"/> GPIO Settings	
Configure the below parameters :	
Search : <input type="text" value="Search (Ctrl+F)"/>	
<input checked="" type="checkbox"/> Basic Parameters	Baud Rate: 115200 Bits/s Word Length: 8 Bits (including Parity) Parity: None Stop Bits: 1
<input checked="" type="checkbox"/> Advanced Parameters	Data Direction: Receive and Transmit Over Sampling: 16 Samples Single Sample: Disable
<input checked="" type="checkbox"/> Advanced Features	Auto Baudrate: Disable TX Pin Active Level Inversion: Disable RX Pin Active Level Inversion: Disable Data Inversion: Disable TX and RX Pins Swapping: Disable Overrun: Enable DMA on RX Error: Enable MSB First: Disable
<input type="button" value="Restore Default"/> <input type="button" value="Apply"/> <input type="button" value="Ok"/> <input type="button" value="Cancel"/>	

SPI BME280 Library for STM32


The BME280 Library for STM32F446 developed by Bosch was adapted for STM32L4


Download <http://communication.minatec.inpg.fr/toussaint/STM32/stm32-bme280-master.tar.gz>

Uncompress it with winzip or equivalent




To be copied into the Drivers subdirectory of the project








In the Keil environment
Create the group Drivers/BME280



Add the following files into BME280 folder.



Adding paths to the « include » files driving the BME280 components



Part I : measuring temperature and pressure in polling mode

Includes to be added in file main.c

```
/* USER CODE BEGIN Includes */
#include <stdio.h>
#include "bme280.h"
/* USER CODE END Includes */

/* USER CODE BEGIN PV */
struct bme280_t mybme280;
/* USER CODE END PV */

/* USER CODE BEGIN PFP */
/* Private function prototypes -----*/
s32 bme280_data_readout_template(void);
/* USER CODE END PFP */
```

Lines to be added in file main.c

```
/* Infinite loop */
/* USER CODE BEGIN WHILE */
while (1){
/* USER CODE END WHILE */
/* USER CODE BEGIN 3 */
    int status=bme280_data_readout_template();
    printf("status %d\n", status);
    HAL_Delay(1000);
}
/* USER CODE END 3 */

/* USER CODE BEGIN 4 */
int fputc(int ch, FILE *f){
    uint8_t c=(uint8_t) (ch & 0x00FF);
    HAL_UART_Transmit(&huart2,&c,1,10);
    return ch;
}
/* USER CODE END 4 */
```

The measurements are done in polling mode and therefore waste a lot of CPU time and power consumption.

Running the NucleoL4_BME280 project


- Compile the project sources within the keil environment

- Download the binary into the MCU

- Install a serial terminal like Termite


https://www.compuphase.com/software_termite.htm

- Reset the MCU for running and enjoy




Serial Terminal Configuration


- Run Terminate



Part II - Interrupt managed by a timer




The goal is to reduce the power consumption. One measures temperature and pressure at regular intervals and puts the MCU in a sleep mode between two successive measurements. A timer with a counter is used. An update Event is generated when counter reaches a given value.




The calculations of “Prescaler” (PSC) and “Counter Period” (ARR) parameters are carried out using the MikroElektronika application “timer calculator”

An interrupt is generated each $T=10\mu s$, using SysClock =32 MHz
ARR et PSC are such as $T = (ARR+1)*(PSC+1)/32e6$



To be reported in timer configuration



TIM2 Configuration

☒ Parameter Settings
 ☒ User Constants
 ☒ NVIC Settings
 ☒ DMA Settings

Configure the below parameters :

Search :

Counter Settings

Prescaler (PSC - 16 bits value)

Counter Mode

Counter Period (AutoReload Register - 16 bits value)

Internal Clock Division (CKD)

4999

Up

63999

No Division

Trigger Output (TRGO) Parameters

Master/Slave Mode

Trigger Event Selection


Disable (no sync between this TIM (Master) and its Slaves)

Update Event

Trigger Event Selection
TIM_MasterOutputTrigger


Apply Ok Cancel

NVIC Settings



Enable the TIM2 global interrupt

HAL Library TIM with IT flow



```
/* USER CODE BEGIN Includes */
/* USER CODE END Includes */

/* USER CODE BEGIN 2 */
HAL_TIM_Base_Start_IT(&htim2);
/* USER CODE END 2 */

/* USER CODE BEGIN 4 */
void HAL_TIM_PeriodElapsedCallback(TIM_HandleTypeDef *htim){
    __NOP();    // only for debugging
}

/* USER CODE END 4 */
```

Details of the Infinite loop in main

```
/* Infinite loop */
/* USER CODE BEGIN WHILE */

while (1)
{
    /* USER CODE BEGIN 3 */
    HAL_SuspendTick();
    HAL_PWR_EnterSLEEPMode(PWR_LOWPOWERREGULATOR_ON, PWR_SLEEPENTRY_WFI);

    HAL_ResumeTick();
    int status=bme280_data_readout_template();
    printf("status %d\n", status);
}
/* USER CODE END WHILE */
```

Running the NucleoL4_BME280 project

- Compile the project sources within the keil environment
- Download the binary into the MCU
- Install a serial terminal for windows like Termite
- Reset the MCU for running and enjoy

